



Beerzym® COMBI

Enzyme combination product for glucan and starch degradation and to improve filtration capacity in breweries

Product description

Beerzym® COMBI is an enzyme combination preparation consisting of thermolabile and thermostable fungal- β -glucanase, as well as a fungal amylase for glucan and starch degradation for the improvement of the filtration capacity and performance in breweries.

Beerzym® COMBI improves filtration capacity and performance during beverage filtration and thus equally increases the total capacity. Beerzym® COMBI acts on colloiddally dissolved substances in the beverage, specially α - and β -glucans, moreover on polyphenols and proteins which may lead to reduced filter throughput, respectively to a clogging of the filter.

When applying Beerzym® COMBI the food regulations of the individual countries currently in force have to be adhered to. For the use as a Filter cartridge cleaner this is not necessary.

Dosage

Beerzym® COMBI is ideally added to the beverage e. g. into the storage tank, in a concentration of 100 - 250 mL/hL.

For breweries brewing according to the purity law - which means, the addition to the product is not allowed - the following application in the course of filter regeneration can be used as alternative:

A 0.2 - 0.5 % solution of Beerzym® COMBI is prepared and is pumped in circuit through the filter plant. It is very important to adjust the pH-value of the solution to pH 4.1 - 5.0. An organic or a diluted inorganic acid can be used for this purpose, respectively NaOH or KOH. The optimum of activity of the solution is in the temperature range between 30 - 55 °C. Ideally, the solution is run in intervals, i.e. pumping phase approx. 15 minutes, detention time 20 - 30 minutes. The operation of the total cycle depends on the degree of soiling of membranes or filter unit which can be followed up by a decrease in pressure differences.

Storage

Optimal storage is at 0 - 10 °C. Higher storage temperatures lead to reduced shelf life. Avoid temperatures above 25 °C. Reseal opened packagings tightly and use up soon.



ERBSLÖH Geisenheim GmbH • Erbslöhstraße 1 • 65366 Geisenheim, Germany
Tel.: +49 6722 708-0 • Fax: +49 6722 6098 • info@erbsloeh.com • www.erbsloeh.com